



Aquastain

- Description:** Interior wiping stain.
- Where to use:** All interior timber that has not been previously painted with a solid paint. Not recommended for previously stained or painted surfaces unless completely stripped and cleaned. We recommend you test it on an off cut or section of the job that is out of sight first.
- How to apply:** Good surface preparation makes your finished paintwork look better, last longer and helps ensure a better, more professional final job.
Sand where necessary to remove imperfections. Ensure the surface is clean, dry and free of all dirt, dust, grease and grime. Apply with either brush or rag and allow to dry. Then apply 2 coats of Clear Finish to provide protection.
- Adequate stirring before use is essential for correct colour and even coverage. Stir well. Where you have more than one can of the same colour for a job, to ensure absolute colour accuracy, we suggest you mix the contents of all the cans together.
- Drying Time:** **Aquastain** will touch dry within 6 hours ready for a second coat after 24 hours drying in temperatures of 25°C and average humidity. Under cooler and more humid conditions expect longer drying times.
- Try to avoid exposure to steam and condensation for 48 hours after painting.
Avoid washing new work for about a week.
- Coverage:** One litre will cover approximately 12 square metres per litre on dressed timber and approximately 6 square metres per litre on rough sawn timber
- Clean up:** Clean up equipment with water.

The information supplied is presented in good faith and has been derived from sources believed to be reliable. Since conditions of use are beyond our control all risks are assumed by the user.

KEEP OUT OF REACH OF CHILDREN

Harmful if swallowed. If swallowed, do not induce vomiting, call nearest poisons information centre.

Keep away from flame and heat.

Avoid breathing spray mist.